


# 9. EXPLODED VIEWS AND PARTS LIST

NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.

- The  $\triangle$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Screws adjacent to  $\nabla$  mark on product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

## 9.1 PACKING SECTION



**(1) PACKING SECTION PARTS LIST**

| <u>Mark</u> | <u>No.</u> | <u>Description</u>                            | <u>Part No.</u>        |
|-------------|------------|-----------------------------------------------|------------------------|
| ⚠           | 1          | Power Cord                                    | See Contrast table (2) |
|             | 2          | AC Adapter                                    | See Contrast table (2) |
| NSP         | 3          | USB Cable                                     | DDE1128                |
|             | 4          | Leaflet                                       | DRH1496                |
|             | 5          | Operating Instructions<br>(Quick Start Guide) | See Contrast table (2) |
|             | 6          | Warranty                                      | See Contrast table (2) |
| NSP         | 7          | Packing Pad                                   | DHA1959                |
|             | 8          | Packing Pad                                   | DHA1960                |
|             | 9          | Sheet                                         | RHX1006                |
|             | 10         | Packing Case                                  | DHG3592                |
| NSP         | 11         | Master Carton                                 | See Contrast table (2) |
|             | 12         | Polyethylene Bag                              | AHG7117                |

**(2) CONTRAST TABLE**

SYXJ, UXJCB and FWLPWXJ are constructed the same except for the following:

| Mark | No. | Symbol and Description                     | SYXJ    | UXJCB   | FWLPWXJ |
|------|-----|--------------------------------------------|---------|---------|---------|
| ⚠    | 1   | Power Cord                                 | ADG1154 | XDG3052 | ADG1154 |
| ⚠    | 2   | AC Adapter                                 | DWR1571 | DWR1571 | DWR1572 |
| NSP  | 5   | Operating Instructions (Quick Start Guide) | DRH1473 | DRH1474 | DRH1475 |
|      | 6   | Warranty                                   | DRY1270 | No used | No used |
|      | 11  | Master Carton                              | DHG3601 | DHG3593 | DHG3602 |